



1. Always clean BePlas Elite PVC panels regularly so that soil & dirt will not build up.
2. Panels can be washed with soapy water or diluted detergents. Specialist cleaning agents may also be used for certain environments. Always check manufacturer's data and test a small area of the panel before applying cleaners over the full panel surface.
3. A soft cloth, sponge or a soft brush may be used for cleaning purposes.
4. Hot water pressure cleaning can also be used, providing a temperature of 60°C is not exceeded.